



Shock Assembly Replacement Instructions

Tools Needed:

Phillip screwdriver
Flat head screwdriver
Channel lock pliers
Vice grip pliers
Rag or shop towel
4mm hex wrenches x 2

Removal:

- 1.) Move the shock into the second position (Note: closest to you when standing at the handlebar)
- 2.) Grasping the black knob with your hand, use a Phillips screwdriver to remove the screw which attaches the pull cord to the shock mount
- 3.) Using the black knob, rotate the shock mount until you see the opening of the C-clip facing the frame of the stroller (Note: the C-clip is located next to the spring at the base of the shock)
- 4.) Using a small flat head screwdriver, insert the flat portion of the screwdriver in the cut out groove of the C-clip and pry away from the stroller (Note: using a rag to cover the shock when this is done will protect your eyes and prevent the C-clip from disappearing during removal)
- 5.) Press the black knob inward towards the seat of the stroller. On the backside you will notice the silver shock mounting pin protruding from the shock guide
- 6.) Grasp the mounting pin with a pair of vice grips and lock onto it
- 7.) With the channel locks, grip the black knob and turn counter clockwise (Note: the knob is held in place with loc-tite and may be difficult to turn at first. Use a rag to cover the knob to help protect it from being scratched)
- 8.) With the black knob off, release the vice grips on the backside of the mounting pin and slide it out of the shock base
- 9.) Using the 4mm hex wrenches, remove the sex bolt holding the top of the shock to the frame

Installation:

- 1.) Compress the spring a little bit and slide into position in the shock base
- 2.) Position the shock base into the shock slider bracket
- 3.) Slide the silver shock mounting pin into position, making note of the groove in the mount (Note: this is the groove that the c-clip will slide into)
- 4.) Insert the C-clip where the groove is. Groove is located at the end of the spring away from the seat of the stroller (Note: if c-clip doesn't go on easily you can tap it with a hammer or end of a screwdriver; this will seat it in place)
- 5.) Apply loc-tite to the threads of the black knob and screw it on to the mounting pin

- 6.) Rotate the top of the shock upward into position in the frame bracket
- 7.) Insert the sex bolt into top of the shock and tighten
- 8.) Reinstall the pull cord and tighten the screw into place while grasping the shock knob
- 9.) Shock is now installed and the stroller can be used right away